

Spreader settings



ACCUPRO® 360ST

Settings for **Single Pass (SP)**
and **Double Pass (DP)** applications

Product	SmartSpread™ setting	Spread width	Setting to deliver g/m ²										
			5 g/m ²	10 g/m ²	15 g/m ²	20 g/m ²	25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²	45 g/m ²	50 g/m ²	
ProTurf	H	4,2 m	SP				12	13	14	15	16	17	18
			DP				10	10 ½	11	11 ½	12	12 ½	13
Sierrablen	C	4,5 m	SP						16	17	18 ½	20 ½	23
			DP						12 ½	13	13 ½	14	15
Sierrablen Mini	F	3,5 m	SP				9	10	11 ½	12 ½	14	15 ½	16 ½
			DP						8 ½	9	9 ½	10	10 ½
Sierrablen Plus	F	4 m	SP					11 ½	12 ½	13 ½	14 ½	15 ½	16 ½
			DP					9	9 ½	10	10 ½	11	11 ½
Sierrablen Plus Pearl (CRF formulations)	F	3,5 m	SP					10 ½	11 ½	12	13	13 ½	14 ½
			DP						9	9 ½	10	10 ½	11
Sierrablen Plus Pearl (Turf Starter 5-28-0)	E	4 m	SP				11	12	13	14	15	16	17
			DP				8 ½	9 ½	10	10 ½	11	11 ½	12
Sierraform GT	F	3,5 m	SP			9 ½	10	11	11 ½	12	13	13 ½	14
			DP				8 ½	9	9 ½	10		10 ½	11
Sportsmaster	G	4 m	SP				9 ½	10 ½	11 ½	12 ½	13 ½	14 ½	15 ½
			DP				6 ½	7 ½	8	8 ½	9 ½	10	10 ½
Sportsmaster Base	I	4 m	SP				8 ½	9 ½	10 ½	11 ½	12 ½	13 ½	15
			DP				6 ½	7	7 ½	8	8 ½	9	9 ½
Sportsmaster CRF	C	4 m	SP						17	18	19 ½	21 ½	
			DP						14	14 ½	15	15 ½	16
Sportsmaster CRF Mini	H	4 m	SP				12	13	14	15	15 ½	16 ½	17 ½
			DP				9	10	10 ½	11	12	12 ½	13
STEP Hi Mag	G	4 m	SP	8	9	10							
			DP	7 ½	8	8 ½							

The spreader settings are guidelines only. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.

For the latest spreader settings, please refer to the product page on the ICL website.

icl-growingsolutions.com

