

# Spreader Settings

## To help with the accurate application of your fertilizer dressings

These recommended spreader settings are given for a walking speed of approximately 5km/hr. These settings are for guidance only.

Exact rates, using the settings here, cannot be guaranteed – rates depend on the spreader itself and the accuracy of the operator. Calibrate the spreader at regular intervals, including effective spreading width.

### Drop Spreader Settings for SS-2 Single Pass at FULL RATE

Spreader	Type	Amount of Product Applied (g/m <sup>2</sup> ) After One Pass										
		5	10	15	20	25	30	35	40	45	50	55
<b>Greenmaster Pro-Lite</b>	All Analyses		3¾	4	4½	5	5¼	5½	6	6¼	6½	
<b>Sportsmaster</b>	All Analyses (not including CRF Range)		3¾	4	4½	5	5¼	5½	6	6¼	6½	
<b>SierraformGT</b>	All Analyses		3¼	3¾	4¼	4¾	5¼	5¾	6¼	6½		
<b>STEP Hi-Mag</b>	Trace Elements	2	2¾	3½								
<b>H2Pro</b>	Granules		3¾	4¼	4¾							

### Drop Spreader Settings for Classic Drop Spreader Single Pass at FULL RATE

Spreader	Type	Amount of Product Applied (g/m <sup>2</sup> ) After One Pass										
		20	25	30	35	40	45	50	55	60	65	70
<b>SierraformGT</b>	All Analyses	4		5	6							
<b>Sierrablen Plus</b>	All Analyses				6.75		7.25					
<b>Sierrablen</b>	All Analyses				13.0		14.5			12.5 (x2)		
<b>H2Pro</b>	Wetting Agent	6.25										

