Spreader Settings for Grass Seed

Accupro Spreader Settings for grass seed in g/m²

		All Bent	Fescue	Ultrafine 30	Extreme	Multi Sport	80/20	Ultrafine 60
Spread Width	С	1m	1.5m	1.5m	1.5m	1.5m	1.5m	1.5m
Cone Setting	C1/2	5	5	5	5	5	5	5
Setting	D							
	D½							
	E							
	E½							
	F							
	F1/2							
	G	2						
	G ½							
	Н	6						
	H¹/₂							
	I	14.5						
	I½	20						
	J							
	J1/2							
	K				5	5		
	K¹/2							
	L				10	10		5
	L¹/₂							
	М				12.5	12.5	5	10
	M¹/2							
	N		5	5	15	15	10	12.5
	N¹/2							

It is important to sow seed at the correct depth, a spreader should only be used to spread seed on cultivated ground where it can be raked into the surface to the required depth.

Seed sowing depths can be found in the Grass Seed section of the Turf Care Shop on our website:

https://www.collier-turf-care.co.uk/Catalogue/Turf-Care-Shop/Grass-Seed-Turf







Spreader Settings for Grass Seed

Accupro Spreader Settings for grass seed in g/m²

		All Bent	Fescue	Ultrafine 30	Extreme	Multi Sport	80/20	Ultrafine 60
Spread Width	0		10	12.5	20	20	15	15
Cone Setting	01/2							
	Р		15	20	25	25	20	22.5
	P¹/2							
	Q		20				25	
	Q ½			25				25
	R		25		30	30		
	R1/2			30			30	30
	S		30					
	S ½							
	Т			35	35	35		35
	T ½		35				35	
Setting	U							
	U½							
	V		40	40	40	40		40
	V¹/2							
	W							
	W¹/₂							
	Х		45	45	45	45		45
	X1/2							
	Υ							
	Y1/2							
	Z				50	50		50





For more information on grass seed or to order, contact your local Area Technical Sales representative or our office



