

ACCUPRO[®] 360ST

The AccuPro 360ST is a new professional rotary spreader engineered to meet the highest standards of turf management.

ACCUPRO® 360ST



Central to this new spreader is the innovative SmartSpread™ system, ensuring even and precise application of granular fertilisers.

With a robust stainless-steel frame and a maintenance-free gearbox, the AccuPro 360ST delivers superior performance and reliability.

ACCUPRO® 360ST



SmartSpread™ is an advanced system that ensures even and precise distribution of granular fertilisers, essential for achieving consistent and uniform application every time.

SmartSpread™

SmartSpread™ directs granules on the impeller based on their size and weight. For example, applications of ProTurf or Sierrablen Plus, which consist of larger and heavier granules, are directed towards the centre of the impeller to gain the necessary centrifugal force for effective spreading.

Conversely, applications of products like Sierraform GT, which consist of smaller and lighter granules, are placed closer to the outer edge of the impeller where less force is required for even distribution.

This precise adjustment ensures each granule type is accurately accounted for, resulting in an optimal spread pattern and promoting uniform turf health.

ACCUPRO® 360ST



Key points

SmartSpread™

Ensures precise application every time.

Stainless Steel Frame

Built for durability, withstands frequent use and harsh conditions, providing long-lasting reliability.

High capacity, durable hopper

30kg capacity hopper shaped to enhance the flow of granules to the impeller, preventing clumping and ensuring a continuous, smooth flow of granular fertilisers.

Ergonomic Handle

Designed for comfort, reducing operator fatigue during extended use.

Removable Rain Cover

Protects the product if being applied during adverse weather conditions.

Maintenance-Free Gearbox

No greasing required, ensuring smooth and consistent performance with minimal upkeep.

Pneumatic Turf Tyres

Distributes weight evenly, preventing turf damage and ensuring smooth mobility across different surfaces.

Open/Shut-Off Control

Easy control of material flow, enhancing operational efficiency.

Integrated Front Handle

Allows for safe and simple lifting, making transportation and handling easy.

Three-year warranty

The AccuPro 360ST comes with a three-year limited warranty.

ACCUPRO® 360ST



Calibration

Calibration of the spreader is automatically performed during assembly.

ACCUPRO® 360ST



Summary

The AccuPro 360ST sets a new standard in fertiliser spreading technology, with SmartSpread™ at its core.

This innovative feature, combined with a maintenance-free gearbox and a durable stainless-steel frame, ensures the AccuPro 360ST provides reliable, efficient, and precise application of granular fertilisers.

Robust, built to last, and industry-leading, the AccuPro 360ST is the ideal choice for consistent and precise applications for high-quality turf maintenance.

Spreader settings



ACCUPRO® 360ST

Settings for **Single Pass (SP)**
and **Double Pass (DP)** applications

Product	SmartSpread™ setting	Spread width	Setting to deliver g/m ²										
			5 g/m ²	10 g/m ²	15 g/m ²	20 g/m ²	25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²	45 g/m ²	50 g/m ²	
Greenmaster Pro-Lite Autumn *	F	3,2 m	SP			10	11	11 ½	12 ½	13	13 ½	14 ½	15
			DP			9	9 ½	10	10 ½	11		11 ½	
Greenmaster Pro-Lite Autumn MG *	I	3,5 m	SP				9 ½	10	11	11 ½	12	12 ½	13
			DP			7 ½	8	8 ½	9	9 ½		10	
Greenmaster Pro-Lite Cold Start *	G	3,5 m	SP			10	11	12	12 ½	13 ½	14	14 ½	15
			DP			9	9 ½	10	10 ½	11	11 ½	12	
Greenmaster Pro-Lite Double K CalMag *	G	3,2 m	SP			9	9 ½	10 ½	11	11 ½	12 ½	13	14
			DP			8	8 ½	9		9 ½	10	10 ½	
Greenmaster Pro-Lite Invigorator *	G	3,2 m	SP			9 ½	10 ½	11 ½	12 ½	13	14	15	15 ½
			DP			8 ½	9	9 ½	10	10 ½	11	11 ½	
Greenmaster Pro-Lite Invigorator Plus *	F	3,0 m	SP			9	10	10 ½	11 ½	12 ½	13	13 ½	14 ½
			DP			8	8 ½	9	9 ½	10	10 ½	11	
Greenmaster Pro-Lite NK *	G	3,4 m	SP			8	9 ½	10 ½	11 ½	12	13	14	15
			DP			7	7 ½	8	9	9 ½	10	10 ½	
Greenmaster Pro-Lite Spring and Summer *	G	3 m	SP			8 ½	9 ½	10	11	12	12 ½	13	14
			DP			7	8	8 ½	9	9 ½		10	
Greenmaster Pro-Lite Turf Tonic *	G	3,5 m	SP			9	10	11	11 ½	12 ½	13	13 ½	14 ½
			DP			10	11	12		13	14	15	
Gronamic Golf	G	4 m	SP				12 ½	14	15 ½	17 ½	19 ½	21 ½	24 ½
			DP			9	9 ½	10 ½	11 ½	12 ½	13	14	
Gronamic Sport	G	3,5 m	SP				13	14	14 ½	16	17	18 ½	21
			DP			11	11 ½	12	12 ½	13	13 ½	14	
Landscaper Pro Triple Action	H	3,5 m	SP							11 ½			
			DP						9				
Landscaper Pro Spring & Summer / Autumn & Winter	H	4,2 m	SP				12	13	14	15	16	17	18
			DP			10	10 ½	11	11 ½	12	12 ½	13	

* Greenmaster Pro-Lite settings are listed separately due to variations in product density across different analyses.

The spreader settings are guidelines only. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.

For the latest spreader settings, please refer to the product page on the ICL website.

icl-growingsolutions.com



Spreader settings



ACCUPRO® 360ST

Settings for **Single Pass (SP)**
and **Double Pass (DP)** applications

Product	SmartSpread™ setting	Spread width	Setting to deliver g/m ²										
			5 g/m ²	10 g/m ²	15 g/m ²	20 g/m ²	25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²	45 g/m ²	50 g/m ²	
ProTurf	H	4,2 m	SP				12	13	14	15	16	17	18
			DP				10	10 ½	11	11 ½	12	12 ½	13
Sierrablen	C	4,5 m	SP						16	17	18 ½	20 ½	23
			DP						12 ½	13	13 ½	14	15
Sierrablen Mini	F	3,5 m	SP				9	10	11 ½	12 ½	14	15 ½	16 ½
			DP						8 ½	9	9 ½	10	10 ½
Sierrablen Plus	F	4 m	SP					11 ½	12 ½	13 ½	14 ½	15 ½	16 ½
			DP					9	9 ½	10	10 ½	11	11 ½
Sierrablen Plus Pearl (CRF formulations)	F	3,5 m	SP					10 ½	11 ½	12	13	13 ½	14 ½
			DP						9	9 ½	10	10 ½	11
Sierrablen Plus Pearl (Turf Starter 5-28-0)	E	4 m	SP				11	12	13	14	15	16	17
			DP				8 ½	9 ½	10	10 ½	11	11 ½	12
Sierraform GT	F	3,5 m	SP			9 ½	10	11	11 ½	12	13	13 ½	14
			DP				8 ½	9	9 ½	10		10 ½	11
Sportsmaster	G	4 m	SP				9 ½	10 ½	11 ½	12 ½	13 ½	14 ½	15 ½
			DP				6 ½	7 ½	8	8 ½	9 ½	10	10 ½
Sportsmaster Base	I	4 m	SP				8 ½	9 ½	10 ½	11 ½	12 ½	13 ½	15
			DP				6 ½	7	7 ½	8	8 ½	9	9 ½
Sportsmaster CRF	C	4 m	SP						17	18	19 ½	21 ½	
			DP						14	14 ½	15	15 ½	16
Sportsmaster CRF Mini	H	4 m	SP				12	13	14	15	15 ½	16 ½	17 ½
			DP				9	10	10 ½	11	12	12 ½	13
STEP Hi Mag	G	4 m	SP	8	9	10							
			DP	7 ½	8	8 ½							

The spreader settings are guidelines only. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.

For the latest spreader settings, please refer to the product page on the ICL website.

icl-growingsolutions.com

